

POLYPHRASE FIRMWARE UPDATE


VONGON

There is new firmware available for Polyphrase, version 2.4. If your Polyphrase has the new firmware, the purple TRIG light will blink **four times** when you power on the pedal.

Firmware v2.4 Updates:

- Improved MIDI clock sync accuracy and stability

How to update POLYPHRASE firmware



1. Power on POLYPHRASE while **holding down both footswitches**. The TRIG and ECHO LEDs should start to slowly blink, indicating that the pedal is ready to load new firmware.

2. Play the firmware **.WAV file** into the **IN L** jack. You can use a phone, computer, audio interface, etc.

✓ **Loading correctly:** The TRIG LED will blink quickly for 5–10 seconds, then the ECHO LED will blink once. This process repeats until the firmware is completely loaded.

✗ **Cannot read file:** Both the TRIG and ECHO LEDs will blink quickly. Power off the pedal and try again. Lowering the playback volume often helps the pedal read the file more clearly. If playing from a phone or computer, silence all notification sounds before starting — any audio interruption during playback will cause the update to fail.

When the firmware is loaded, POLYPHRASE will restart automatically. If your pedal has the new firmware, the purple TRIG light will blink **four times** when the pedal is powered on.

Please contact support@vongon.com for questions.